


Three-phase multifunction energy meter

EXW4-4ETH

User Guide V1.0



Safety Information - Important Information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service or maintain it. The following special messages may appear throughout this bulletin or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, can result in death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, can result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury. The safety alert symbol shall not be used with this signal word.

Please Note

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Nova for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Table of Contents

Chapter 1. Overview	- 1 -
1.1. Introduction.....	- 1 -
1.2. Characteristics	- 1 -
1.3. Parameters.....	- 2 -
Chapter 2. Technical parameters specification	- 2 -
2.1. Specification.....	- 2 -
2.2. Installation dimensions.....	- 4 -
2.3. Wiring Diagrams.....	- 5 -
Chapter 3. General function description	- 6 -
3.1. Multi-tariffs function.....	- 6 -
3.2. Demand calculation method.....	- 7 -
Chapter 4. Operation	- 7 -
4.1. Meter startup instructions	- 7 -
4.2. LCD display area description	- 8 -
4.3. Button definition description	- 9 -
4.4. Description of display screen	- 9 -
4.4.1. Main display screen.....	- 9 -
4.4.2. Auxiliary display screen	- 13 -
4.5. Setting-up	- 14 -
4.5.1. Set communication class parameters.....	- 16 -
4.5.2. Set CT class parameters	- 17 -
4.5.3. Set PT class parameters	- 18 -
4.5.4. Set system class parameters.....	- 19 -
4.5.5. Set demand class parameters	- 23 -
4.5.6. Set time class parameters.....	- 24 -
4.5.7. Set ethernet class parameters.....	- 26 -
Appendix	- 31 -
Appendix A – LCD character definition table	- 31 -
Appendix B – Failure code reference table	- 31 -
Appendix C – Alarm prompt comparison table	- 31 -

Chapter 1. Overview

1.1. Introduction

EXW4 series products are three phase DIN rail installation multi-function energy meter. This series of products can support measurement and analysis of variety of power parameters, such as voltage, current, the four quadrant power parameters, power factor, harmonic content etc. ; Meanwhile they also can provide the measurement of multiple electric energy parameters , such as two way active energy, reactive energy, monthly and daily electricity consumption statistics. This series of products also can support the analysis of electric power parameter measurement in 1P2W, 3P4W, 3P3W grid environment, is suitable for power monitoring for photovoltaic inverter , new energy electricity consumption statistic analysis, real time power monitoring and a variety of other environments, has the multi-function, high stability and long life characteristics. This series of products with RJ45, RS485 or MBUS communication interface, baud rate maximum support 38400bps, supporting Modbus RTU, Modbus TCP, MBUS communication protocols. It can easily realize the function of remote data read, and adopt the design of large-screen LCD and touch-sensitive key, which can easily carry out the local view and set operation of variety parameters. The product has the function of password protection, which ensures the data security of the product.

EXW4 series products are multi-functional electric energy meters designed for electric energy monitoring of photovoltaic inverter, statistical analysis of new energy electricity consumption, power monitoring needs of power system utilities and intelligent buildings. Its complete communication function is very suitable for various control systems, SCADA systems and energy management systems.

1.2. Characteristics

- External current transformers of output types such as **1-5A/333mV** are supported, and direct access of **Rogowski coil** is also supported. With the current transformer reverse connection correction function.
- Support external voltage transformer access, input voltage minimum support 30V.
- DIN Rail mounting, standard 4 modulus width.
- Touch button design improves button operability and reduces button failure rate
- Multi-function parameter measurement, providing voltage, current, active power, reactive power, apparent power, power factor, phase Angle, etc.
- To provide the analytical data of the total harmonic contents of voltages and currents
- Provide a variety of statistical data and local storage functions, such as two-way power, demand and other statistical data. Provide monthly electricity consumption statistics for the last 12 months and daily electricity consumption statistics for the last 31 days
- supports the dual-timing function of the meter startup running time and load running time.
- supports the access of a 2-tariff switching signal for metering at 2-tariff energy.
- Support TCP/IP communication function, support Modbus TCP. **Support with gateway working mode.**
- Support RS485 communication function, baud rate up to 38400bps, support Modbus RTU protocol.
- LCD refresh time is 1 second, support manual or automatic scroll display (configurable)

1.3. Parameters

1. The Unit can measure and display	
Instantaneous RMS Values	
Current	Per phase, neutral
Voltage	L-L, L-N
Frequency	45 to 65Hz
Active power	Total and per phase
Reactive power	Total and per phase
Apparent power	Total and per phase
Power factor	Total and per phase
Energy Values (include: import, export, import + export)	
Active energy	0 to 99999999.999 kWh (LCD display number of digits: 6+2 -> 7+1 -> 8+0)
Reactive energy	0 to 99999999.999 kvarh (LCD display number of digits: 6+2 -> 7+1 -> 8+0)
Multi-Tariff active energy (T1 - T4)	0 to 99999999.999 kWh (LCD display number of digits: 6+2 -> 7+1 -> 8+0)
Maximum Demand Values	
Max.Demand of current	Per phase
Max.Demand of active power	Total
Max.Demand of reactive power	Total
Max.Demand of apparent power	Total
2. The Unit can measure and communication read	
Energy Values	
Apparent Energy (total)	0 to 99999999.999 kVAh
Per phase energy	Active energy and reactive energy, include: import, export, import+export Range: 0 to 999999.999 kWh/kvarh
Multi-Tariff reactive energy (T1 - T4)	0 to 99999999.999 kvarh, include: import, export, import+export
Monthly electricity consumption for the last 12 months	Total active energy Range: 0 to 99999999.999 kWh
Daily energy consumption for the last 31 days	Total active energy Range: 0 to 99999999.999 kWh
3. The Unit can settable	
Communication class	Modbus address, baud rate, parity bit, stop bit
Current transformer (CT) class	CT1 (Primary), range from 1 to 9999 CT2 (Secondary), range is 1 or 5
Voltage transformer (PT) class	PT1 (Primary), range from 30 to 500000 PT2 (Secondary), range is 30 to 500
System configuration class	User password (HMI), Power system type, gateway mode
Demand class	Demand interval period, Slide time
Time class	Automatic scroll display time, Backlight time, System time (RTC), Tariff time
TCP/IP class	DCHP, IP address, Subnet mask, Default gateway, IP port


Chapter 2. Technical parameters specification

2.1. Specification

Electrical Characteristics		
Type of measurement		RMS including harmonics on AC system, support 1P2W, 3P3W, 3P4W
Measurement accuracy	Voltage, Current	Class 0.5, according IEC 61557-12
	Active power	Class 0.5, according IEC 61557-12
	Reactive power	Class 2, according IEC 61557-12
	Apparent power	Class 1, according IEC 61557-12
	Active energy	Class 0.5S, according IEC 62053-22, IEC 61557-12
	Reactive energy	Class 2, according IEC 62053-23, IEC 61557-12
	Power factor	Class 1, according IEC 61557-12
	Frequency	Class 0.2, according IEC 61557-12
	Harmonic distortion	Class 2, according IEC 61557-12
Data update rate		1 second. Optional 100 ms
Input-Voltage	Rate voltage (Un)	230 Vac (L-N) / 400 Vac (L-L)
	Measured range (Direct connection)	30 to 300 Vac (L-N), 30 to 500 Vac (L-L)
	PT primary	30 to 500000
	Impedance	1MΩ
	Frequency range	45 to 65 Hz
	Overload capacity	2*Un for 1 second
Input-Current	CT2 (Secondary)	1A or 5A 333mV Rogowski coils (50mV, 85mV, 100mV/kA @50Hz)
	CT1 (Primary)	1 to 9999 A
	Measured range	0.003 to 6 A, basic current (Ib) is 5A
	Impedance	<0.01 ohm
	Overload capacity	120A for 0.5 second
Auxiliary power supply	Operating range	80 ~ 300 Vac / 100 ~ 420 Vdc
	Frequency	45 ~ 65 Hz
	Power consumption	< 4VA/0.5W
Real-time clock accuracy		0.5 s/d
Mechanical Characteristics		
IP Degree of Protection (IEC 60529)		Designed to IP51 front display, IP30 meter body
Dimensions (W x H x D)		72 x 100 x 66 mm
Mounting Position		DIN Rail mounting
Material of meter case		UL 94 V-0
Environmental Characteristics		
Operating Temperature		-25 to +55°C
Storage Temperature		-40 to +80°C
Humidity		< 90%, non-condensing
Pollution Degree		2
Altitude		Up to 2000m
Vibration		10 Hz to 150Hz, IEC 60068-2-6
Electromagnetic Characteristics		
Electrostatic Discharge		Level 4, according IEC 61000-4-2 ⁽¹⁾
Immunity to Radiated Fields		Level 3, according IEC 61000-4-3 ⁽¹⁾





Immunity to Electrical Fast Transients	Level 4, according IEC 61000-4-4 ⁽¹⁾
Immunity to Surges	Level 4, according IEC 61000-4-5 ⁽¹⁾
Immunity to Conducted Disturbances	Level 3, according IEC 61000-4-6 ⁽¹⁾
Immunity to Magnetic Fields	IEC 61000-4-8 ⁽¹⁾
Immunity to Voltage Dips	IEC 61000-4-11 ⁽¹⁾
Radiated Emissions	Class B, according EN55011
Conducted Emissions	Class B, according EN55011
Harmonics	IEC 61000-3-2 ⁽¹⁾
(1): The experimental test is carried out according to the grade requirements of industrial grade products in IEC61326-1	
Safety	
Measurement Category	CAT III, according IEC 61010-1
Overvoltage Category	CAT III, according IEC 61010-1
Insulation	AC Voltage Test: 4kV for 1 minute
	Impulse Voltage Test: 6kV - 1.2/50µs waveform
Protective Class	II, according IEC61010-1
BUS Communications	
Interfaces standard and protocols	2-wire RS485, Modbus RTU
Buad rate	1200 to 38400 bps, default is 9600 bps
Parity bit	None, Even, Odd, default is None
Stop bit	1 or 2, default is 1
Response time	<100ms
Transmission mode	half-duplex
Transmission distance	Up to 1000m
Max. Bus loading	64 pcs
TCP Communications	
Interface Standard	10/100M Base-T Auto-Negotiation
Protocols	Modbus TCP
Gateway function	Support Modbus TCP to RTU gateway function

2.2. Installation dimensions



2.3. Wiring Diagrams

Measurement input wiring	
<p>3P4W (3CT)</p>	<p>3P4W (3PT+3CT)</p>
<p>3P3W (2CT)</p>	<p>3P3W (2PT+2CT)</p>
<p>2P3W (L+L+N, 2CT)</p>	<p>1P2W (L+N, 1CT)</p>
<p>1P2W (L+L, 1CT)</p>	<p>1P2W (L+N, 3CT)</p>
Auxiliary power wiring	
<p>AC Power</p>	<p>DC Power</p>

	
<p>Communication terminal wiring</p>	
<p>Single meter wiring</p>	<p>Multiple meters wiring</p>
	
<p>A : 500 mA fast fuse.</p>	
<p>Terminal specification parameters</p>	
<p>Voltage measurement input terminal</p>	<p>Wire size: 0.82 ~ 3.31 mm² (18 ~ 12 AWG) Torque: 0.5 ~ 0.6 N.m</p>
<p>Current measurement input terminal</p>	<p>Wire size: 1.318 ~ 3.31 mm² (16 ~ 12 AWG) Torque: 0.5 ~ 0.6 N.m</p>
<p>Auxiliary power terminal</p>	<p>Wire size: 0.82 ~ 3.31 mm² (18 ~ 12 AWG) Torque: 0.5 ~ 0.6 N.m</p>
<p>Communication terminal</p>	<p>Wire size: 0.82 ~ 3.31 mm² (18 ~ 12 AWG) Torque: 0.5 ~ 0.6 N.m</p>


Chapter 3. General function description

3.1. Multi-tariffs function

The multi-tariffs function refers to the function that the meter realizes time-sharing measurement of electric quantity. The power meter divides the 24 hours of a day into several time periods, and then specifies the rate number for each time period. Then the power meter accumulates the amount of electricity in time division according to the pre-divided time period, and stores it to the position of the rate number corresponding to each time period, so as to realize the function of time-division measurement of electricity.

The meter used the method of the tariff number correlation to the starting time point to realize the tariff segment division. The power meter support up to 8 starting time points and up to 4 tariff segments (T1, T2, T3 and T4).

Figure 3-1: The starting time points of the tariff segment




As shown in Figure 3-1, 06:10 designated as the start time of tariff 1 (T1), 12:00 designated as the start time of tariff 2 (T2), 18:00 designated as the start time of tariff 3 (T3), 21:00 designated as the start time of tariff 4 (T4), so tariff 1 time range is 06:10 to 12:00, tariff 2 time range is 12:00 to 18:00, tariff 3 time range is 18:00 to 21:00, tariff 4 time range is 21:00 to tomorrow 06:10.

Note: The tariff parameters can be set by communication commands (Please refer to the relevant communication protocol document for the register address).

3.2. Demand calculation method

The block intervals are sliding, the power meter calculates and update the demand at the sliding speed.

Figure 3-2: Diagram of sliding block interval calculation method






As shown in Figure 3-2, the first demand calculation is made at the 15th minute, and the demand calculation data is between the 0th and the 15th minute. At the 16th minute, do the second demand calculation, and the demand calculation data is between the 1th and the 16th minute. At the 17th minute, do the third demand calculation, and the demand calculation data is between the 2th and the 17th minute.


Chapter 4. Operation

4.1. Meter startup instructions

After the EXW4 series products are properly wired and connected to the power supply, the products will first enter the self-test process, under which the LCD screen display sequence is shown as follows:

First screen display	Display full screen characters	
Second screen display	Displays the software version number of the power meter	
Three screen display	Display the results of the self-test	

4.2. LCD display area description



A: The power grid type icon represents the current measurement type of the meter.

B: Maximum demand icon.

C: Direction icon for import and export energy.

D: A status indicator icon for the meter.

E: An icon of a unit of measurement data.

F: Battery status icon and lock icon, displays the battery status and dicates that the device is locked.

G: Measured values.

H: An icon of digital I/O status for the meter.





I: Multi tariff icon indicating the tariff segment to which the current energy. ► represents the tariff number displayed as the running tariff segment. For example: **T2** ► The figure on the left represents that the tariff 2 (T2) segment is running, and the accumulated energy will be counted into the corresponding energy area of tariff 2 (T2).

J: Warning Status icon.

K: Channel indicator icon for multiple measurement channels.

L: Quadrant indicator icon indicating the quadrant of the current load.







4.3. Button definition description








Button	Definition	Click	Press 3 second
	Button 1: Escape key (Esc)	1. In the setting screen or auxiliary screen: exit or return to the previous screen. 2. In the main display screen: page scroll for parameters such as voltage and current.	Under the main display screen: enter the auxiliary display screen.
	Button 2: Up key (Up)	1. In the main display screen: view the power factor, maximum demand. 2. In the setting screen or auxiliary screen: scroll up to display the page or the increasing number.	Null
	Button 3: Down key (Dn)	1. In the main display screen: view the power information. 2. In the setting screen or auxiliary screen: scroll down to display the page or the decreasing number.	Null
	Button 4: Enter key (Et)	1. In the main display screen: view energy data and system time. 2. In the setting screen: right move the setting cursor.	1. In the main display screen: enter the setting mode. 2. In the setting screen: enter the setting state or carry out confirmation operation.








4.4. Description of display screen









4.4.1. Main display screen

After the meter is powered on and passes the self-test process, the interface entered is defined as the main display interface, which is used to display the main measurement parameters, electric quantity data, instrument information and other data of the product. Users can scroll the display page by pressing the button 1 to button 4.

LCD display	Description
Display screen under button 1	
	<p>A display screen for three-phase L-N voltage.</p> <p>Example: L1-N voltage = 230.0V L2-N voltage = 230.0V L3-N voltage = 230.0V</p> <p>Note: In 3P3W mode, this screen is not displayed</p>
	<p>A display screen for three-phase L-L voltage.</p> <p>Example: L1-2 voltage = 400.0V L2-3 voltage = 400.0V L3-1 voltage = 400.0V</p> <p>Note: In 1P2W mode, this screen is not displayed</p>
	<p>A display screen for three-phase current.</p> <p>Example: L1 current = 5.001A L2 current = 5.002A L3 current = 5.000A</p>
	<p>A display screen for three-phase L-N voltage THD.</p> <p>Example: L1 voltage THD = 3.06% L2 voltage THD = 2.78% L3 voltage THD = 4.35%</p>
	<p>A display screen for three-phase L-L voltage THD.</p> <p>Example: L1-2 voltage THD = 2.74% L2-3 voltage THD = 3.80% L3-1 voltage THD = 0.00%</p> <p>Note: This screen is displayed only in 3P3W mode.</p>
	<p>A display screen for three-phase current THD.</p> <p>Example: L1 current THD = 3.56% L2 current THD = 2.45% L3 current THD = 1.87%</p>
Display screen under button 2	








 <p>The screen shows a power triangle diagram on the left with a shaded area representing power factor. On the right, the display shows '1.000 PF' and '50.00 Hz'.</p>	<p>Total power factor and frequency display screen</p> <p>Example: Total power factor = 1.000 Frequency = 50.00Hz</p>
 <p>The screen shows a power triangle diagram on the left. On the right, the display shows '1.000 PF' for L1, '1.000 PF' for L2, and '1.000 PF' for L3.</p>	<p>Three - phase power factor display screen</p> <p>Example: L1 power factor = 1.000 L2 power factor = 1.000 L3 power factor = 1.000</p>
 <p>The screen shows a power triangle diagram on the left. On the right, the display shows '5.000 A' for L1, '5.000 A' for L2, and '5.000 A' for L3.</p>	<p>Max.demand of three-phase display screen</p> <p>Example: Max.Demand of L1 current = 5.000A Max.Demand of L2 current = 5.000A Max.Demand of L3 current = 5.000A</p>
 <p>The screen shows a power triangle diagram on the left. On the right, the display shows '3.680 kW' for total active power, '5.701 kvar' for total reactive power, and '3.598 kVA' for total apparent power.</p>	<p>Max.demand of total active/reactive/apparent power display screen</p> <p>Example: Max.Demand of total active power = 3.680 kW Max.Demand of total reactive power = 5.701 kvar Max.Demand of total apparent power = 3.598 kVA</p>
<p>Display screen under button 3</p>	
 <p>The screen shows a power triangle diagram on the left. On the right, the display shows '1.150 kW' for L1, '1.150 kW' for L2, and '1.150 kW' for L3.</p>	<p>Per phase active power display screen</p> <p>Example: L1 active power = 1.150 kW L2 active power = 1.150 kW L3 active power = 1.150 kW</p>
 <p>The screen shows a power triangle diagram on the left. On the right, the display shows '0.000 kvar' for L1, '0.000 kvar' for L2, and '0.000 kvar' for L3.</p>	<p>Per phase reactive power display screen</p> <p>Example: L1 reactive power = 0 kvar L2 reactive power = 0 kvar L3 reactive power = 0 kvar</p>
 <p>The screen shows a power triangle diagram on the left. On the right, the display shows '1.150 kVA' for L1, '1.150 kVA' for L2, and '1.150 kVA' for L3.</p>	<p>Per phase apparent power display screen</p> <p>Example: L1 apparent power = 1.150 kVA L2 apparent power = 1.150 kVA L3 apparent power = 1.150 kVA</p>

 <p>The display shows a power triangle with active power (P) on the horizontal axis and reactive power (Q) on the vertical axis. The hypotenuse represents apparent power (S). The values displayed are: 3.450 kWh, 0.000 kvar, and 3.450 kVA.</p>	<p>Total active/reactive/apparent power display screen</p> <p>Example: Total active power = 3.450 kW Total reactive power = 0 kvar Total apparent power = 3.450 kVA</p>
<p>Display screen under button 4</p>	
 <p>The display shows a power triangle and the value 30.10 kWh.</p>	<p>Total active energy</p> <p>Example: Total active energy = 30.10 kWh</p>
 <p>The display shows a power triangle and the value 15.05 kWh.</p>	<p>Import active energy</p> <p>Example: Import active energy = 15.05 kWh</p>
 <p>The display shows a power triangle and the value 15.05 kWh.</p>	<p>Export active energy</p> <p>Example: Export active energy = 15.05 kWh</p>
 <p>The display shows a power triangle, the value 63.42 kWh, and a tariff icon (T with a right arrow).</p>	<p>Tariff 1 active energy</p> <p>Example: Tariff 1 active energy = 63.42kWh</p>
 <p>The display shows a power triangle, the value 28.63 kWh, and the label T2.</p>	<p>Tariff 2 active energy</p> <p>Example: Tariff 2 active energy = 28.63kWh</p>
 <p>The display shows a power triangle, the value 83.55 kWh, and the label T3.</p>	<p>Tariff 3 active energy</p> <p>Example: Tariff 3 active energy = 83.55kWh</p>

	<p>Tariff 4 active energy</p> <p>Example: Tariff 4 active energy = 93.26kWh</p>
	<p>Total reactive energy</p> <p>Example: Total reactive energy = 2363.49kvarh</p>
	<p>Import reactive energy</p> <p>Example: Import reactive energy = 2300.26kvarh</p>
	<p>Export reactive energy</p> <p>Example: Export reactive energy = 63.23kvarh</p>
	<p>Displaying the current date of the system real-time clock.</p> <p>Example: The current date is June 4, 2021</p>
	<p>Displaying the current time of the system real-time clock.</p> <p>Example: The current time is 14:32.38</p>
<p>Icon description of the load nature:</p> <p> is mean : The load is an inductive load ,  is mean : The load is a capacitive load.</p>	


4.4.2. Auxiliary display screen

Under the main display screen, press button 1 for 3 second to enter the screen of auxiliary display. At this point, click button 2 or button 3 can be scroll the page needs to be viewed. Under the screen of auxiliary display, can click button 1 to return to the main display screen. If there is no button operation in more than 1 minute under the screen of auxiliary display, the meter will automatically return to the main display screen.

LCD display	Description
	Modbus address Example: The modbus address is 1.
	Baud rate Example: The baud rate is 9600bps.
	Parity bit Example: The Parity bit is None.
	Ratio of current transformer (CT)
	Ratio of voltage transformer (PT)
	The serial number of meter Example: The serial number is 21000110.
	Software version number

4.5. Setting-up

The logical diagram of the parameter setting menu is as follows:



How to enter the "Parameter setting Menu" screen:

Step 1: In the main display screen, press button 4 for 3 second to enter the user password input mode.



Note: The user password input screen is shown in the figure on the right.

Step 2: Enter the correct user password and press button 4 for 3 second to confirm.

How to enter a password:

A: Click button 2 and button 3 to increase or decrease the number of flashing bits.

B: Click button 4 to move the flashing position to the right.

C: After entering the correct password, press button 4 for 3 second for confirmation. If the






password is verified correctly, the power meter will enter the screen of "Parameter Setting menu".

Note: Under the user password input screen, can click button 1 to return to the main display screen. If there is no button operation in more than 1 minute under this screen, the power meter will automatically return to the main display screen.

4.5.1. Set communication class parameters

Communication parameters include: Modbus address, baud rate, parity bit, stop bit.







<p>1. After entering the "Parameter Setting Menu" screen, select the setting screen (as shown in the figure below), and then press button 4 for 3 second to enter the communication parameter setting screen.</p>	
<p>2. Setting the modbus communication address</p>	
	<p>Modbus address setting range: 001 to 247, default is 001.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to exit the setting menu and return to the previous setting screen.</p>
	<p>Click button 2 or button 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>3. Setting the baud rate</p>	
	<p>Baud rate can be setting: 1200, 2400, 4800, 9600, 19200, 38400 bps, default is 9600bps.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to exit the setting menu and return to the previous setting screen.</p>

	<p>Click button 2 or button 3 to select the baud rate. Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state. Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>4. Setting the parity bit</p>	
	<p>Parity bit can be setting: None, Even, Odd, default is None. Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state. Click button 2 or button 3 to scroll the page and select the next setting interface. Click button 1 to exit the setting menu and return to the previous setting screen.</p>
	<p>Click button 2 or button 3 to select the parity bit. Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state. Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>5. Setting the stop bit</p>	
	<p>Stop bit can be setting: 1 or 2, default is 1. Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state. Click button 2 or button 3 to scroll the page and select the next setting interface. Click button 1 to exit the setting menu and return to the previous setting screen. Note: The stop bit can only be set to 2 if the check bit is equal to None.</p>
	<p>Click button 2 or button 3 to select the stop bit. Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state. Click button 1 to exit the setting state without saving the setting parameters.</p>

4.5.2. Set CT class parameters

CT parameters include: primary side value (CT1) and secondary side value (CT2) of the current transformer.

1. After entering the "Parameter Setting Menu" screen, select the setting screen (as shown in the figure below), and then press button 4 for 3 second to enter the system parameter setting screen.

	
<p>2. Select the setting screen (as shown in the figure below), and then press button 4 for 3 second to enter the CT class parameters setting screen.</p>	
	
<p>2.1. Setting CT1</p>	
	<p>CT1 setting range: 1 to 9999A, default is 5A.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 1 to return to the previous level setup menu.</p>
	<p>Click button 2 or 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>2.2. Setting CT2</p>	
	<p>CT2 can be set: 1A or 5A, default is 5A.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 1 to return to the previous level setup menu.</p>
	<p>Click button 2 or 3 to select the CT2.</p> <p>Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>

4.5.3. Set PT class parameters

PT parameters include: primary side value (PT1) and secondary side value (PT2) of the voltage transformer.

1. After entering the "Parameter Setting Menu" screen, select the setting screen (as shown in the


figure below), and then press button 4 for 3 second to enter the system parameter setting screen.



2. Select the setting screen (as shown in the figure below), and then press button 4 for 3 second to enter the PT class parameters setting screen.



2.1. Setting PT1



PT1 setting range: 30 to 500000V, default is 230V.

Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.

Click button 1 to return to the previous level setup menu.



Click button 2 or 3 to increase or decrease the number of set bits.

Click button 4 can be moved the set bits to the right.

Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.

Click button 1 to exit the setting state without saving the setting parameters.

2.2. Setting PT2



PT2 setting range: 30 to 500V, default is 230V.

Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.

Click button 1 to return to the previous level setup menu.



Click button 2 or 3 to increase or decrease the number of set bits.

Click button 4 can be moved the set bits to the right.

Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.

Click button 1 to exit the setting state without saving the setting parameters.


4.5.4. Set system class parameters

System class parameters include: system current direction correction, system type, gateway mode, user password, reset max. demand or historical electricity consumption log.

1. After entering the "Parameter Setting Menu" screen, select the setting screen (as shown in the figure below), and then press button 4 for 3 second to enter the system class parameter setting screen.



2. Setting system current direction correction



Press button 4 for 3 second to enter the next level setting menu.
Click button 2 or button 3 to scroll the page and select the next setting interface.
Click button 1 to return to the previous level setup menu.

2.1. Set L1 current direction correction



L1 current direction correction can be set: forward or reverse, default is forward.

Click button 3 to scroll down to the Settings screen of L2 current direction correction.

Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state.

Click button 1 to return to the previous level setup menu.



Click button 2 or 3 to select the current direction.

Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.

Click button 1 to exit the setting state without saving the setting parameters.

Note: *Frd* represents forward, *rE* represents reverse.

2.2. Set L2 current direction correction



L2 current direction correction can be set: forward or reverse, default is forward.

Click button 3 to scroll down to the Settings screen of L3 current direction correction.

Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state.

Click button 1 to return to the previous level setup menu.








Click button 2 or 3 to select the current direction.

Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.

Click button 1 to exit the setting state without saving the setting parameters.

	<p>Note: <i>Frd</i> represents forward, <i>rE</i> represents reverse.</p>
<h3>2.3. Set L3 current direction correction</h3>	
	<p>L3 current direction correction can be set: forward or reverse, default is forward.</p> <p>Click button 2 to scroll down to the Settings screen of L2 current direction correction.</p> <p>Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state.</p> <p>Click button 1 to return to the previous level setup menu.</p>
	<p>Click button 2 or 3 to select the current direction.</p> <p>Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p> <p>Note: <i>Frd</i> represents forward, <i>rE</i> represents reverse.</p>
<h3>3. Set system type</h3>	
	<p>The system type supported by the power meter includes the five types: 1P2W, 2P3W, 3P3W, 3P4W, default is 3P4W.</p> <p>Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to exit the setting menu and return to the previous setting screen.</p>
	<p>Click button 2 or button 3 to select the system type.</p> <p>Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<h3>5. Setting gateway mode</h3>	
	<p>The gateway mode supported includes the five types: slave and master, default is slave.</p> <p>Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to exit the setting menu and return to the previous setting screen.</p>


	<p>Click button 2 or button 3 to select the gateway mode. Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state. Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>Note:</p> <p>SLAVE represent: The gateway mode is slave. In this mode, the TCP port of the meter can only read its own data.</p> <p>MASTER represent: The gateway mode is master. In this mode, the TCP port of the meter can read its own data, or it can read modbus devices connected to the RS485 port of the meter.</p>	
<p>6. Setting user password</p>	
	<p>User password setting range:0000 to 9999, default is 0000.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state. Click button 2 or button 3 to scroll the page and select the next setting interface. Click button 1 to exit the setting menu and return to the previous setting screen.</p>
	<p>Click button 2 or button 3 to increase or decrease the number of set bits. Click button 4 can be moved the set bits to the right. Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state. Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>7. Reset Max. demand or historical electricity consumption log</p>	
	<p>Press button 4 for 3 second to enter the reset state. Click button 2 or button 3 to scroll the page and select the next setting interface. Click button 1 to exit the setting menu and return to the previous setting screen.</p>
	<p>Click button 2 or button 3 to select the reset options. Press button 4 for 3 second to confirm the reset. The meter will reset the selected option and exit the reset state. Click button 1 to exit the reset state without reset the selected option.</p>
<p>Note:</p> <p>LEG is mean: Historical monthly and historical daily consumption of energy. (this option is supported only for the Multit-tariff meter)</p>	

$d\bar{n}d$ is mean: Max. demand.

4.5.5. Set demand class parameters

Demand class parameters include: demand interval period and sliding time.

1. After entering the "Parameter Setting Menu" screen, select the setting screen (as shown in the figure below), and then press button 4 for 3 second to enter the demand class parameter setting screen.



2. Setting demand interval period



Demand interval period can be set: 0 to 60, unit is minute, default is 60 minutes.

Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.

Click button 2 or button 3 to scroll the page and select the next setting interface.

Click button 1 to return to the previous level setup menu.

Note: If the demand interval period is set to 0 minutes, then the demand is updated every second.




Click button 2 or button 3 to increase or decrease the number of set bits.

Click button 4 can be moved the set bits to the right.

Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state.

Click button 1 to exit the setting state without saving the setting parameters.

3. Setting sliding time




Sliding time setting range: 1 to (demand interval period), unit is minutes, default is 1 minute.

Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.

Click button 2 or button 3 to scroll the page and select the next setting interface.

Click button 1 to return to the previous level setup menu.


Note: The slip time has no effect when the demand interval period is set to 0.

	<p>Click button 2 or button 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
---	---

4.5.6. Set time class parameters

Time class parameters include: backlight time, automatic scroll display time, System time (RTC) and Tariff time.

1. After entering the "Parameter Setting Menu" screen, select the setting screen (as shown in the figure below), and then press button 4 for 3 second to enter the time class parameter setting screen.



2. Setting backlight time



Backlight time can be set: on, off, 5, 10, 30, 60, 120, unit is minute, default is 60 minutes.

Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state.

Click button 2 or button 3 to scroll the page and select the next setting interface.

Click button 1 to return to the previous level setup menu.

Note:

1. The character "on" means the backlight is always on, and "off" means the backlight is always off.

2. If you need to setting other values within 120 minutes, use the communication command to do so.









Click button 2 or button 3 to select the backlight time.



Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.

Click button 1 to exit the setting state without saving the setting parameters.

Note: *on* That means is on. *off* That means is off.


3. Setting automatic scroll display time

	<p>Automatic scroll display time set range: 0 to 60, unit is second, default is 0 second.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to return to the previous level setup menu.</p> <p>Note: Automatic scroll display time is 0, means no automatic wheel display</p>
	<p>Click button 2 or button 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>4. Setting date of RTC</p>	
	<p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to return to the previous level setup menu.</p>
	<p>Click button 2 or button 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>5. Setting system time (RTC)</p>	
	<p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to return to the previous level setup menu.</p>
	<p>Click button 2 or button 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>6. View tariff time</p>	


	<p>View menu for tariff information.</p> <p>Press button 4 for 3 second to enter the screen for view tariff information.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to return to the previous level setup menu.</p> <p>Note: The menu cannot be setting and can only be viewed.</p>
	<p>The screen for displaying the tariff information.</p> <ol style="list-style-type: none">1. The number displayed in the first line of the screen represents the sequence number of the selected starting time point. The meter supports 8 starting time points and 4 tariff segments.2. The character displayed in the second line of the screen represents the current tariff is T1. The meter supports 4 tariff segments. (T1 to T4)3. The character displayed in the third line of the screen represents the starting time of the tariff segment (format is hours: minutes). <i>FEE1</i> That means tariff segment is tariff 1 (T1). <i>FEE2</i> That means tariff segment is tariff 2 (T2). <i>FEE3</i> That means tariff segment is tariff 3 (T3). <i>FEE4</i> That means tariff segment is tariff 4 (T4). <p>Click button 1 scroll the page and select the next screen.</p> <p>Press button 1 for 3 second to exit the setting state without saving the setting parameters.</p> <p>Note: If FEE0 is displayed, the time segment is invalid and does not belong to any tariff.</p>

4.5.7. Set ethernet class parameters

The ethernet class parameters include: DHCP, IP address, subnet mask, default gateway, IP port and save ethernet parameter.

<p>1. After entering the "Parameter Setting Menu" screen, select the setting screen (as shown in the figure below), and then press button 4 for 3 second to enter the ethernet class parameter setting screen.</p>  <p>Note: After completing the Ethernet parameter settings, you need to enter the parameter saving setting menu and perform the parameter saving operation. Otherwise, the set parameters will not</p>
--

be saved to the meter.	
2. Setting DHCP	
	<p>The DHCP function can be set to on or off, default is off.</p> <p>Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to exit the setting menu and return to the previous setting screen.</p>
	<p>Click button 2 or button 3 to select the DHCP function.</p> <p>Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>Note: DHCP is dynamic host configuration protocol.</p> <p>If the DHCP is set on, the IP address of the instrument will be automatically assigned by devices such as routers; If the DHCP is set off, the IP address of the instrument needs to be manually set.</p>	
3. Setting IP address	
	<p>Setting menu for IP address.</p> <p>Press button 4 for 3 second to enter the screen for view IP address.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to return to the previous level setup menu.</p>
	<p>The IP address display screen.</p> <p>A complete IP address is displayed on four screens to display the values of each field separately.</p> <p>The number in the bottom left corner of the screen represents the field number of the IP address currently displayed.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to return to the previous level setup menu.</p>
	<p>Click button 2 or button 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>Note: Example of a complete IP address display screen.</p>	



The IP address value for the example is 192.168.1.200

4. Setting subnet mask




Setting menu for subnet mask.

Press button 4 for 3 second to enter the screen for view subnet mask.

Click button 2 or button 3 to scroll the page and select the next setting interface.

Click button 1 to return to the previous level setup menu.



The subnet mask display screen.

A complete subnet mask is displayed on four screens to display the values of each field separately.

The number in the bottom left corner of the screen represents the field number of the subnet mask currently displayed.

Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.

Click button 2 or button 3 to scroll the page and select the next setting interface.

Click button 1 to return to the previous level setup menu.




Click button 2 or button 3 to increase or decrease the number of set bits.

Click button 4 can be moved the set bits to the right.

Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.

Click button 1 to exit the setting state without saving the setting parameters.

Note: Example of a complete subnet mask display screen.



The subnet mask value for the example is 255.255.255.0

5. Setting default gateway










Setting menu for default gateway.

Press button 4 for 3 second to enter the screen for view default gateway.

Click button 2 or button 3 to scroll the page and select the next setting interface.

Click button 1 to return to the previous level setup menu.

	<p>The default gateway display screen.</p> <p>A complete default gateway is displayed on four screens to display the values of each field separately.</p> <p>The number in the bottom left corner of the screen represents the field number of the default gateway currently displayed.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to return to the previous level setup menu.</p>
	<p>Click button 2 or button 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The power meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<p>Note: Example of a complete default gateway display screen.</p>	
	
<p>The default gateway value for the example is 192.168.1.1</p>	
<h2>6. Setting IP port</h2>	
	<p>The IP port setting range:1 to 9999, default is 502.</p> <p>Press button 4 for 3 second to enter the setting state, and the digit of the setting becomes the flashing state.</p> <p>Click button 2 or button 3 to scroll the page and select the next setting interface.</p> <p>Click button 1 to exit the setting menu and return to the previous setting screen.</p>
	<p>Click button 2 or button 3 to increase or decrease the number of set bits.</p> <p>Click button 4 can be moved the set bits to the right.</p> <p>Press button 4 for 3 second to confirm the setting. The meter will save the setting value and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the setting parameters.</p>
<h2>7. Saving the ethernet parameters</h2>	

	<p>The ethernet parameter save setting menu for the meter.</p> <p>Press button 4 for 3 second to enter the setting state, and the character of the setting becomes the flashing state.</p> <p>Click button 2 to scroll the page and select the next setting interface.</p> <p>Click button 1 to exit the setting menu and return to the previous setting screen.</p>
	<p>Press button 4 for 3 second to confirm the setting. The meter will save the ethernet parameters and exit the setting state.</p> <p>Click button 1 to exit the setting state without saving the ethernet parameters.</p>
<p>Note: After setting the Ethernet parameters, it is necessary to perform the parameter save setting operation in this menu in order to save the set parameters to the meter. If the saved parameters are not set, the set ethernet parameters will not be saved</p>	

Appendix


Appendix A – LCD character definition table

0	1	2	3	4	5	6	7	8	9
A	B	C	D	E	F	G	H	I	J
K	L	M	N	O	P	Q	R	S	T
U	V	W	X	Y	Z				

Appendix B – Failure code reference table

No.	LCD display	Fault description
1	Err-01	The battery voltage is too low.
2	Err-02	The ethernet module failure.
3	Err-03	The battery voltage is too low and the ethernet module failure.

Appendix C – Alarm prompt comparison table

No.	The action of the meter	Alarm definition
1	LCD display alarm icon 	Occurs over voltage, over current or power exceeds the limit